

L2+ Managed Gigabit Switch

WGSD-10020HP

WGSW-24040 series

WGSW-20160HP

Quick Installation Guide

Table of Contents

1. Package Contents	3
2. Requirements	4
3. Terminal Setup	5
3.1 Logging on to Console	6
3.2 Configuring IP Address.....	6
3.3 Storing current switch configuration	8
4. Starting Web Management	9
4.1 Logging in to the Managed Switch	9
4.2 Saving Configuration.....	12
5 Recovering Back to Default Configuration.....	13
6. Customer Support	14

1. Package Contents

Thank you for purchasing PLANET WGSW-Managed Gigabit Switch series. The descriptions of this series are shown below:

Model	TP Port	Fiber Port	Combo Port	PoE Budget
WGSD-10020HP	8	2		150W
WGSW-20160HP	16	-	4	230W
WGSW-24040	24	-	4	-
WGSW-24040R	24	-	4	-
WGSW-24040HP	24	-	4	220W
WGSW-24040HP4	24	-	4	440W

“Managed Switch” is used as an alternative name in this Quick Installation Guide.

Open the box of the Managed Switch and carefully unpack it. The box should contain the following items:

- The Managed Switch x 1
- Quick Installation Guide x 1
- DB9 to RS232 Cable x 1
- Rubber Feet x 1
- Two Rack-mounting Brackets with Attachment Screws x 1
- Power Cord x 1
- SFP Dust-proof Caps

Model	SFP Dust-proof Caps
WGSD-10020HP	2
WGSW-20160HP	4
WGSW-24040	4
WGSW-24040R	4
WGSW-24040HP	4
WGSW-24040HP4	4

If any item is found missing or damaged, please contact your local reseller for replacement

2. Requirements

- Workstations running Windows 10/XP/2003/Vista/7/8/2008, MAC OS X or later, Linux, UNIX, or other platforms are compatible with TCP/IP protocols.
- Workstations are installed with Ethernet NIC (Network Interface Card)
- Serial Port Connection (Terminal)
 - The above Workstations come with COM Port (DB9) or USB-to-RS232 converter.
 - The above Workstations have been installed with terminal emulator, such as Tera Term, PuTTY or Hyper Terminal included in Windows XP/2003.
 - Serial cable -- one end is attached to the RS232 serial port, while the other end to the console port of the Managed Switch
- Ethernet Port Connection
 - Network cables -- Use standard network (UTP) cables with RJ45 connectors.
 - The above PC is installed with Web browser and JAVA runtime environment plug-in.



Note

It is recommended to use Internet Explorer 8.0 or above to access the Managed Switch. If the Web interface of the Managed Switch is not accessible, please turn off the anti-virus software or firewall and then try it again.

3. Terminal Setup

To configure the system, connect a serial cable to a COM port on a PC or notebook computer and to DB9 type of serial port of the Managed Switch.




Figure 3-1: Managed Switch Console Connectivity

A terminal program, such as Tera Term or PuTTY, is required to make the software connection to the Managed Switch.

1. Run terminal program on the OS.
2. When the following screen appears, make sure that the COM port should be configured as:

- Baud: 115200
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: None




Figure 3-2: COM Port Configuration

3.1 Logging on to Console

Once the terminal is connected to the device, power on the Managed Switch, and the terminal will display “running testing procedures”. Then, the following message asks to log in user name and password. The factory default user name and password are shown as follows and the login screen in Figure 3-3 appears.

Username: **admin**
Password: **admin**




Figure 3-3: Managed Switch Console Login Screen

The user can now enter commands to manage the Managed Switch. For a detailed description of the commands, please refer to the following chapters.



Note

1. For security reason, please change and memorize the new password after this first setup.
2. Only accept command in lowercase letter under console interface.

3.2 Configuring IP Address


The Managed Switch is shipped with default IP address shown below.

IP Address: **192.168.0.100**
Subnet Mask: **255.255.255.0**

To check the current IP address or modify a new IP address for the Managed Switch, please use the procedures as follows:

■ Show the current IP Address

1. At the “#” prompt, enter “show ip interface brief”.
2. The screen displays the current IP address as shown in Figure 3-4.




```
COM5 - PuTTY
Username: admin
Password:
WGSW-24040# show ip interface brief
Interface Address Method Status
-----
VLAN 1 192.168.0.100/24 Manual UP
WGSW-24040#
```

Figure 3-4: IP Information Screen

■ Configuring IP Address

3. At the “#” prompt, enter the following command and press <Enter> as shown in Figure 3-5.

```
WGSW-24040 # configure terminal
WGSW-24040 (config)# interface vlan 1
WGSW-24040 (config-if-vlan)# ip address 192.168.1.100 255.255.255.0
```



```
COM5 - PuTTY
WGSW-24040 (config)# exit
WGSW-24040# configure terminal
WGSW-24040 (config)# interface vlan 1
WGSW-24040 (config-if-vlan)# ip address 192.168.1.100 255.255.255.0
WGSW-24040 (config-if-vlan)#
```

Figure 3-5: Configuring IP Address Screen

The previous command would apply the following settings for the Managed Switch.

```
IP Address: 192.168.1.100  
Subnet Mask: 255.255.255.0
```

4. Repeat step 1 to check if the IP address has changed.


If the IP is successfully configured, the Managed Switch will apply the new IP address setting immediately. You can access the Web interface of the Managed Switch through the new IP address

3.3 Storing current switch configuration

In the Managed Switch, the running configuration sequence `running-config` can be saved from the RAM to FLASH by **“copy”** command, so that the running configuration sequence becomes the start-up configuration file, which is called configuration save.

At the “#” prompt, enter the following command and press <Enter>.

```
# copy running-config startup-config
```



```
COM5 - PuTTY  
WGSW-24040# copy running-config startup-config  
Building configuration...  
do not reset or power off the device!  
% Saving 4565 bytes to flash:startup-config  
WGSW-24040# █
```

Figure 3-6: Saving Current Configuration Command Screen



Note

If you are not familiar with the console command or the related parameter, enter “help” anytime in console to get the help description.

4. Starting Web Management

The following shows how to start up the **Web Management** of the Managed Switch. Note the Managed Switch is configured through an Ethernet connection. Please make sure the manager PC must be set to the same **IP subnet address**.

For example, the default IP address of the Managed Switch is **192.168.0.100**, then the manager PC should be set to **192.168.0.x** (where x is a number between 1 and 254, except 100), and the default subnet mask is 255.255.255.0.




Figure 4-1: IP Management Diagram


4.1 Logging in to the Managed Switch

1. Use Internet Explorer 8.0 or above Web browser and enter IP address **http://192.168.0.100** (the factory default IP address or the one that you have just changed in console) to access the Web interface.
2. When the following dialog box appears, please enter the default user name and password "admin" (or the password you have changed via console). The login screen in Figure 4-2 appears.

Default IP Address: **192.168.0.100**

Default Username: **admin**

Default Password: **admin**



Authentication required

http://192.168.0.100
Your connection to this site is not private

Username

Password

Figure 4-2: Login Screen

3. After entering the password, the main screen appears as Figure 4-3 shows.



Figure 4-3: Web Main Screen of Managed Switch

The Switch Menu on the top of the Web page lets you access all the commands and statistics the Managed Switch provides. The Switch Menu always contains one or more buttons, such as **“Refresh”**, **“Save”**, **“Help”** and **“Logout”**.



Figure 4-4: Switch Menu




Figure 4-5: Switch Menu -- System



Note

If you are not familiar with Switch functions or the related parameter, press **“Help icon”** anytime on the Web page to get the help description.


Now, you can use the Web management interface to continue the Switch management or manage the Switch by console interface.

Please refer to the user’s manual for more.


4.2 Saving Configuration

To save all applied changes and set the current configuration as a startup configuration on the Web user interface, the startup-configuration file will be loaded automatically across a system reboot.


1. Click the **Save** icon on the top Switch Menu bar.



2. Press the **"Save Configuration"** button.



3. Or the other way to save the setting is to Click **Maintenance, Save Startup Config**.



5 Recovering Back to Default Configuration

■ IP address has been changed or admin password has been forgotten –

To reset the IP address to the default IP address "192.168.0.100" or reset the login password to default value, press the hardware reset button on the front panel for about 10 seconds. After the device is rebooted, you can log in the management Web interface within the same subnet of 192.168.0.xxx.




Figure 5-1: WGSD-10020HP Reset Button




Figure 5-2: WGSW-24040 series Reset Button




Figure 5-3: WGSW-20160HP Reset button

6. Customer Support

Thank you for purchasing PLANET products. You can browse our online FAQ resource and User's Manual on PLANET Web site first to check if it could solve your issue. If you need more support information, please contact PLANET switch support team

PLANET online FAQs:

<https://www.planet.com.tw/en/support/faq>

Switch support team mail address:

support@planet.com.tw

WGSD-10020HP, WGSW-24040 Series and WGSW-20160HP User's Manual:

<https://www.planet.com.tw/en/support/downloads?&method=keyword&keyword=WGS&view=2#list>



(Please select your switch model name from the drop-down menu of Product Model.)

Copyright © PLANET Technology Corp. 2018.

Contents are subject to revision without prior notice.

PLANET is a registered trademark of PLANET Technology Corp.

All other trademarks belong to their respective owners.

